

A close-up, low-angle shot of a car's headlight and side mirror, rendered in a clean, minimalist style with soft lighting and a white background. The car's body panels are smooth and reflective, with subtle shadows and highlights that emphasize its curves and lines. The headlight is prominent in the upper right, and the side mirror is visible below it. The overall aesthetic is sleek and modern.

LEXUS EXTRA CARE **Certified**
Offered by Lexus Financial Services

FACTORY-BACKED
VEHICLE SERVICE AGREEMENT

What is a Vehicle Service Agreement?

VSA's cover the cost of mechanical breakdowns beyond your vehicle's Lexus Certified Limited Warranty. Depending on how many miles you drive and how long you plan to keep your vehicle, LFS offers a protection plan that's right for you.

The LFS VSA offers you:

VALUE

- Helps guard against the rising costs of covered parts and labor
- Limits out-of-pocket costs on covered repairs

PEACE OF MIND

- Access to a nationwide service network of Lexus dealers throughout the U.S. and Canada
- Factory-trained service technicians use only Lexus-approved parts
- Backed by the strength and stability of Lexus

CONVENIENCE


- Reimbursement for towing, substitute transportation, meals and lodging**
- Claims are paid directly to the dealer

Want to learn more? Contact your local Lexus dealer.

**If your vehicle becomes inoperable due to mechanical failure of a covered component.

Drive with confidence knowing you are protected with a Vehicle Service Agreement (VSA) backed by Lexus.

VSA PROTECTS YOUR VEHICLE BEYOND THE LEXUS CERTIFIED LIMITED WARRANTY*



*Depending on the age and mileage of the vehicle, it may also be eligible for coverage under the vehicle's basic and powertrain warranties

Lexus Financial Services (LFS) offers VSA plans that fit your driving needs. Ask your Lexus dealer for details.

LEXUS EXTRA CARE Certified Plan

For Lexus Certified Pre-Owned Vehicles

ELIGIBILITY

Lexus Certified Pre-Owned vehicles at time of purchase or lease.

COVERAGE

There are many plans available – one to fit your driving needs. Ask your Lexus dealer for details.¹

Time/Total Vehicle Mileage

4 years/Up to 125,000 miles

5 years/Up to 125,000 miles

6 years/Up to 125,000 miles

¹ Time and mileage coverage periods are measured from the effective date of the original Certified Limited Warranty and zero miles. Coverage expires upon reaching the time or mileage of the coverage period, whichever occurs first. There is no deductible for each eligible repair visit. Please see your Lexus dealer for details on the Lexus Certified Limited Warranty.

What's Covered²

The **Certified** Plan covers all specified parts below.

ENGINE

All internally lubricated components and: Air Control Valve (ACV); Air Pump; Balance Shaft; Belt Tensioner; Camshaft; Crankcase Ventilation Valve; Crankshaft; Crankshaft Pulley; Cylinder Heads; Engine Block; Engine Mounts; Engine Oil Reservoir; Engine Oil Reservoir Pump; Equipment Drive Shaft; Exhaust Gas Recirculation Valve; Exhaust Manifolds; Exhaust Manifold Heat Insulator; Exhaust Pipe Gasket; Flexplate; Flywheel; Idler Pulley; Intake Air Control Valve (IACV); Intake Manifold; Mixture Control Valve; Oil Cooler; Oil Filter Bracket Subassembly; Oil Pan; Oil Pressure Switch; Oil Pump; Oil Sending Unit; Pair Valve (Reed Valve); Piston; Rotary Engine Components (including Apex Seal, Bearings, Eccentric Shaft, and Rotor); Seals and Gaskets; Supercharger; Supercharger Bypass Valve; Supercharger Intercooler; Supercharger Relay; Tensioners; Thermal Vacuum Valve; Thermostatic Valve; Three-Way Catalyst Converter; Timing Belt; Timing Belt Idler; Timing Chain; Timing Cover; Timing Gears; Turbo Intercooler; Turbo Wastegate; Turbocharger; Vacuum Switch; Vacuum Switching Valve; Vacuum Transmitting Valve; Valve Covers; Water Pump

MANUAL TRANSMISSION

Transfer Case Components (All internally lubricated components) and: Clutch Master Cylinder; Clutch Pedal Subassembly; Clutch Release Cylinder; Control Position Indicator Subassembly; Gears and Shafts; Hoses, Lines and Tubes; Master Cylinder Reservoir; Radial Ball Bearing (for Clutch Release) and/or Clutch Fork; Seals and Gaskets; Shift Lever Boot and/or Retainer; Shift Lever Knob; Shift Lever Subassembly; Shift Linkage and Cables; Transfer/Transmission Case; Transmission Mounts

AUTOMATIC TRANSMISSION

Transfer Case Components (All internally lubricated components) and: Hoses, Lines and Tubes; Seals and Gaskets; Shift Linkage and Cables; Solenoids; Torque Converter; Transfer/Transmission Case; Transmission Mounts; Vacuum Modulator

AXLE ASSEMBLY

(Front, Rear, Four-wheel and All-wheel Drive): All internally lubricated components and: 4x4 Actuators; Axles and Bearings; Center Support Bearing; Constant Velocity Joints and Boots; Differential Carrier Assembly; Drive Axle Housing; Drive Shaft; Front Drive Shift Lever Knob; Hubs; Locking Hubs; Seals and Gaskets; Thrust Washers; Universal Joints; Viscous Coupling

HYBRID

Hybrid Vehicle Generator Assembly; Hybrid Vehicle Motor Assembly; Hybrid Vehicle Transaxle Assembly; Transmission Input Damper Assembly; Actuator Assembly Shift Control; Battery Computer Assembly; Battery Current Sensor; Circuit Breaker Sensor; Combination Meter Assembly; Combination Meter Computer; Computer Engine Control; Hybrid Vehicle Battery Blower Assembly; Hybrid Vehicle Battery Blower Motor Control; Hybrid Vehicle Battery Thermistor; Hybrid Vehicle Control Computer; Inverter Assembly with Converter; Main Switch Assembly; Power Source Control Computer Assembly; Power Steering Electronic Control Unit (ECU) Assembly; Power Steering Gear Assembly; Shift Lever Position Sensor; Skid Control Computer Assembly; Steering Column Assembly; Transmission Control Module

SUSPENSION

(Front and Rear): Bushings/Bearings; Control Arm Shafts; Electronic Suspension Actuator/Motor and Compressor; Front and Rear Coil Springs; Front and Rear Stabilizer Bar; Front Leading Arm; Front Spring Assembly; Front Spring Shackle; Radius Arm; Spindle; Spindle Support; Steering Knuckle; Strut Rod; Sway Bar Link; Torsion Bar Spring; Upper and Lower Ball Joints; Upper and Lower Control Arms; Upper Arm Shaft

STEERING

Gear Box internal components and: Bushings/Bearings; Center Link; Horn Contact Ring; Hoses; Lines and Tubes; Idler Arm; Knuckle Stopper Cover; Pitman Arm; Power Steering Pump;

Power Steering Pump Pulley; Rack and Pinion; Seals and Gaskets; Steering Column; Steering Column Coupling; Steering Column Shaft; Steering Dampener; Steering Gear Box and Pump Housings; Tie Rod End

FUEL SYSTEM

Air Flow Meter; Carburetor; Charcoal Canister; Diesel Fuel Injection Pump; Electric Fuel Pump; Electronic Fuel Injection System; Fuel Filler Opening Lid Hinge Spring; Fuel Injectors; Fuel Pressure Regulator; Fuel Pump; Fuel Sending Unit; Fuel Sensors; Fuel Tank; Throttle Body

COOLING SYSTEM

Coolant Level Sensor/Tank; Cooling Fan Relay; Cooling Fan Sensor; Engine Coolant Temperature Switch or Sensor (at radiator); Engine Cooling Fan Motor; Engine Fan; Engine Fan Clutch; Engine Fan Motor; Engine Fan Shroud; Equipment Drive Pulley; Fan Bracket Subassembly; Radiator; Radiator Fan Relay; Seals and Gaskets; Thermostat

AIR CONDITIONING/HEATING

Air Conditioning Lines and Tubes; Air Conditioning Pressure Switches; Air Temperature Control Programmer; Blower Motor; Blower Motor Resistor; Compressor; Compressor Clutch Assembly; Compressor Pulley; Condenser; Condenser Fan and Motor; Cooler Control Switch; Cooler Unit; Damper Servo; Defroster Control Cable; Evaporator; Evaporator Temperature Sensor; Expansion Valve; Heater Control Head; Heater Control Valve; Heater Core; Idler Pulley; Pressure Regulator Assembly; Receiver/Dryer; Schrader Valve; Seals and Gaskets

BRAKE

Anti-Lock Braking/Traction Control Actuator Pump and Motor; Brake Booster; Brake Hoses, Lines and Tubes; Brake Pedal Subassembly; Disc Brake Calipers; Load-Sensing Proportioning Valve; Master Cylinder; Parking Brake Cable; Parking Brake Control Handle Assembly; Parking Brake Lever Subassembly; Parking Brake Pedal Subassembly; Proportioning Valve; Rear Brake Backing Plate; Seals and Gaskets; Wheel Cylinders

ELECTRICAL

Alternator; Automatic-Off Headlamp Sensor Timer and Switches; Automatic Shoulder Belt Motor and Switches;

Automatic Temperature Control Unit; Back-up Light Switch; Battery to Ground Cable; Battery to Starter Cable; Blower Motor; Blower Motor Resistor; Charge Warning Relay; Clutch Starter Interlock Switch; Convertible Top Motor; Cruise Control Actuator/Servo; Cruise Control Sensors and Switches; Cruise Control Vacuum Motor; Defogger Relay; Distributor; Door Control Relay; Engine Coolant Temperature Gauge and Sending Unit; Engine Coolant Temperature Receiver Gauge and Sending Unit; Engine Cooling Fan Motor; Engine Tachometer; Fuel Gauge and Sending Unit; Fuel Receiver Gauge and Sending Unit; Guide Rail Limit Switch; Headlamp Washer; Headlight Control Relay; Horn; Horn (for theft deterrent); Ignition Coil; Ignition Switch Lock Cylinder and Key Set; Integration Relay; Lamp Failure Indicator Sensor; License Plate Light Assembly; Lock Cylinder Set; Main Relay; Manually Operated Switches; Oil Pressure Receiver Gauge and Sending Unit; Power Antenna Motor and Cable; Power Door Lock Actuator; Power Mirror Defogger; Power Mirror Motor; Power Seat Motors; Power Sliding Door Motor; Power Window Motor/Regulator; Rear Shock Absorber Control Actuator; Retractable Headlamp Motor; Shoulder Belt Drive Motor; Smart Entry and Start System Switch, Sensor and ECU; Spark Plug Resistive Cord; Speedometer; Starter Motor; Starter Solenoid; Stop Light Switch; Sunroof Cable; Sunroof Motor; Taillight Control Relay; Turn Signal Flasher; Unlock Warning Buzzer; Windshield Washer Pump; Windshield Wiper Link Assembly; Wiper Control Relay; Wiper Motor; Wiring Harnesses

COMPUTERS AND ELECTRONICS

Airbag Sensors; Antenna Cord; Anti-Lock Braking/Traction Control Computer and Sensors; Automatic Shoulder Belt Computer; Body Control Module; Circuit Opening Relay; Compact Disc (CD) Player; Cruise Control Computer; Driver's Side and Passenger's Side Airbags; Electronic Ignition Unit; Electronically Controlled Transmission/Transfer Case Computer and Sensors; Electronically Modulated Suspension Computer; Engine Control Computer; Front Seat Airbag Assembly; Graphic Equalizer; Knock Sensor; Navigation System; Power Mirror ECU; Power Seat

Computer; Progressive Power Steering Computer; Radio Tuner; Side Impact Airbag; Steering Sensor; Stereo Component Amplifier; Sunroof Control Computer and Relay; Tape Player; Tilt/Telescoping Steering Computer; Traction Control Computer; Trip Computer; Variable Induction System; Vehicle Security Computers and Sensor; Wiper Module

ADDITIONAL COMPONENTS

Accelerator Pedal and/or Bracket Subassembly; Accelerator Pedal Rod Assembly; Back Door Lock Assembly; Convertible Roof Hook; Door Lock Cylinder; Front and Rear Door Lock Assembly; Front Seat Belt; Glove Compartment Door Lock Cylinder; Glove Compartment Door Latch Subassembly; Hood Lock Assembly; Hood Lock Control Cable Assembly; Hood Support Assembly; Rear Seat Belt; Reclining Seat Back Adjuster; Removable Roof Lock Handle; Seat Track Assembly; Shoulder Belt Guide Rail Assembly; Sliding Roof Drive Cable; Sliding Roof Guide Rail; Tail Gate Lock Assembly; Tilt Roof Lock Handle Assembly

ITEMS NOT COVERED

Accessory Drive Belts; Batteries; Body Panels; Brake Linings, Pads and Shoes, Rotors and Drums; Bumpers; Carpet; Chrome; Clutch Friction Disc and Pressure Plate; Dash Cover and Pad; Door Trim, Handles, and Fabric; Filters; Fluids; Glass (including Windshields); Headliner; Heating Hoses, Lines and Tubes; Hinges; Hoses; Hybrid Vehicle Battery Pack; Hybrid Vehicle Battery Plug Assembly; Hybrid Vehicle Relay Assembly; Hybrid Vehicle Supply Battery Assembly; Interior and Exterior Trim Moldings (including but not limited to: Ashtrays, Covers, Cup Holders, and Vents); Lamps (Back-up, Fog Light, Side Marker, and Turn Signal Light Assemblies); Light Bulbs; Nuts, Bolts, Clips, Retainers, and Fasteners; Paint; Rust and Corrosion Damage; Seat Covers; Sheet Metals; Shiny Metals; Spark Plugs; Structural Framework and Welds; Tires; Vacuum Hoses, Lines and Tubes; Weather Stripping; Wheels and Rims; Windshield Wiper Blades (Rubber component)

² Covered components are subject to change.

The only Lexus factory-backed VSA plans available from your Lexus dealer.

This brochure is intended as a sample of vehicle service agreement coverage. Coverage is subject to exclusions and limitations set forth in the vehicle service agreement. The actual coverage, exclusions, and limitations of the agreements may vary both from state to state and according to the program features chosen. In certain states, Toyota Motor Services Company or Toyota Motor Insurance Agency administers vehicle service agreements.

In Florida: Toyota Motor Insurance Company
P.O. Box 9550
Cedar Rapids, IA 52409
Florida License #02871

Lexus Financial Services is a service mark of Toyota Motor Insurance Services, Inc., and its subsidiary, Toyota Motor Insurance Company.



lexusfinancial.com

09-0321 LFS Pre-Owned VSA